

NOT TO SCALE

<u>NOTES</u>

- 1. STRAW ROLES SHALL BE PLACED ALONG SLOPE CONTOURS.
- 2. STRAW ROLL INSTALLATION REQUIRES THE PLACEMENT AND SECURE STAKING OF THE ROLL IN A TRENCH, 3"-5" DEEP, DUG ON CONTOUR. RUNOFF MUST NOT BE ALLOWED TO RUN UNDER OR AROUND ROLL.
- 3. DRIVE STAKE THROUGH MIDDLE OF WATTLE, LEAVING 2"-3" OF STAKE PORTRUDING ABOVE WATTLE.

PLAN NO. CK-E.10 STRAW WATTLES